Welcome! This user's guide has been designed as an easy-to-use reference for the operation of your audiovisual system. For complete instructions, please refer to your owner's manual.

Getting Started:

- Gently touch screen to begin

Starting Up:

- Wait for system to start

PC:

- This button selects PC as the source. This input has no additional controls available.

* Please select the output destination.
The top buttons only select the input source,
so output displays must also be chosen.

HDMI:

- This button selects HDMI Input as the source. This input has no additional controls available.

Doc Cam:

- This button selects Document Camera as the source. This input has no additional controls available.

Apple TV:

- This button selects AppleTV as the source. This also includes transport controls for the device.

* Please select the output destination.
The top buttons only select the input source,
so output displays must also be chosen.

Audio Controls:

- This page allows for raising and lowering volume control and muting for the microphones and program sources.

Help Desk:

- This page provide a contact number for the help desk.

Camera Control:

- This page allows for the ability to select preset positions for either camera or manual control of either camera.